

BF630 Log format exported from USB

For example:

000001,0000000001,2008/02/05,15:34:49,000,001,001,000,001,000

Seq. No.	Card ID	Y/M/D	H/M/S	IN/OUT	Verification Source	Event/Verify Code	FKey	TID	Door
000001	0000000001	2008/02/05	15:34:49	000	001	001	000	1	000

Note:

- IN/OUT indication: Only for Access Control with Entry/Exit indication
0x00 : None, 0x01 : Access IN, 0x02 : Access OUT
- Verification Source
0 = None, 1=Finger, 2=Card, 3=C+F, 4=PIN (Password) , 5= F+P, 6= C+P, 7 = C+F+P
- Event/Verify Code
Authentication Success : 0x01, From external WG Reader : 80, Door open too long: 128,
Door Closed After Alarm : 129, BYPASS ON: 130, BYPASS OFF: 131, Unauthorized User : 132
Unregistered User : 133, Deactivate User: 134, Expired User: 135, Anti Pass back Reject: 136
Disallowed Door: 137, Door Intruded: 138, Double Badge Control Verification Fail: 139
Tamper Switch Breakdown: 140, Exit Button Pressed: 141, Door Closed Normally: 142
Duress Alarm: 143, Fire Alarm: 144, RESV 1: 145, RESV 2:146, Tamper Switch Close: 147

- Function Key
 - 000 : None
 - 016 to 025: F1, F1+1 to F1+9
 - 032 to 041: F2, F2+1 to F2+9
 - 048 to 057: F3, F3+1 to F3+9
 - 064 to 073: F4, F4+1 to F4+9
- Terminal ID: 001 to 255
- Door No. 000: Main Door, 001 to 009: Door No.1 to No.9

BF-630/830-USB Function Operation Guide

1. Attach USB stick to Terminal
2. Get into Management screen → Select 4. MISC → Select 1. for User and Log counters
3. When screen is showing you “Start Write log” : Log is being downloading to USB stick
4. When screen is showing “Write OK” : Log download is OK. IF screen is showing “open File Error” : Log download is fail.

Notice:

1. Error for “open File Error” description.
File name of exported files are saved and sequent by Month/Date/Minute, thus please avoid to write in the file in the same Month/Date/Minute in case the Open File Error.
2. USB stick support FAT .FAT32 .NTFS format
3. Keep USB stick clean, more data saved in the USB stick more longer the Write in time will take.